



CPVC CTS Products Design and Installation Manual



! WARNING



Failure to follow instructions and warnings can result in serious personal injury, property damage, and/or product failure.

- Read and understand all instructions before attempting to install any Spears® CPVC Products.
- Wear safety glasses, hard hat, and foot protection.

TABLE OF CONTENTS

Purpose of This Manual	1	Solvent Cementing Procedures	5
Hazard Identification	1	Joint Assembly	6
Installer Safety Instructions	2	Set and Cure Times	6
Model Codes	2	Transition Joints and Fittings	7
Helpful Information – English and Metric		Assembling Gasket Sealed Brass-Threaded Female Adapter	
Conversion Charts	3	Connections	7
Handling and Storage	3	Assembling Standard Threaded Connections	7
System Listings, Usage, and Standards	3	Engineering Data Section	8
Penetrating Fire-Rated Walls and Partitions	3	Pipe and Fitting Specifications	8
Underslab Installations	4	Pressure Ratings	8
Freeze Protection/Sunlight Exposure	4	Hydraulic Design	8
Hose Bibb Installations	4	Friction Loss & Flow Velocity Chart.....	9
Water Heater Connections.....	4	Hanger Support Spacing	10
Basic Joint Assembly	4	Material Properties	10
Cutting the Pipe	4	Expansion and Contraction	11
Deburring	5	CPVC Piping System Guidelines for Commercial Hot & Cold	
Fitting Preparation	5	Water Distribution Applications	13
		Warranty	Back Cover

PURPOSE OF THIS MANUAL

This manual is intended for use by specifiers, installers, and users in the selection, design, installation, and inspection of CPVC systems installed using Spears® CPVC products. All information contained within this manual is considered vital to obtain proper system performance and must be read and fully understood before attempting to install these products. If you have any questions about the safe and proper installation of these products, contact Spears® Manufacturing Company 15853 Olden Street, Sylmar CA 91342 USA, Telephone (818) 364-1611 • (800) 862-1499.

HAZARD IDENTIFICATION

Definitions for identifying the various hazard levels are provided below.



This safety alert symbol indicates important safety messages. When you see this symbol, be alert to the possibility of personal injury. Carefully read and fully understand the message that follows.

DANGER

The use of the word "DANGER" identifies an immediate hazard with a likelihood of severe personal injury or death if instructions, including recommended precautions, are not followed.

WARNING

The use of the word "WARNING" identifies the presence of hazards or unsafe practices that could result in severe personal injury if instructions, including recommended precautions, are not followed.

CAUTION

The use of the word "CAUTION" identifies possible hazards or unsafe practices that could result in personal injury, product damage, and/or property damage if instructions, including recommended precautions, are not followed.

NOTICE

The use of the word "NOTICE" identifies special instructions that are important but not related to hazards.

INSTALLER SAFETY INSTRUCTIONS

Read and understand this manual before proceeding with the installation and testing of the Spears® CPVC system. Education and a complete understanding of the instructions provided are requirements for the installer of the Spears® CPVC system. These instructions contain important information. If you need additional copies of this manual, or if you have any questions about the safe installation and use of this system, contact Spears® Manufacturing Company 15853 Olden Street, Sylmar CA 91342 USA, Telephone (818) 364-1611 • (800) 862-1499.

1. Inspect the product. Make sure all parts are included with the shipment and that all necessary tools are available for proper installation.
2. Wear safety glasses, hard hat, and foot protection.
3. Avoid dangerous environments. If using electrically powered tools for installation, make sure the area is free from moisture or wetness that could create unsafe working conditions. Keep work areas well lit. Allow sufficient space for measuring and dry-fitting the system.
4. Prevent back injury. Always practice safe lifting and installation techniques.
5. Use only tools specifically designed for plastic pipe and fittings.
6. Work in a well-ventilated area. Ensure that there is proper ventilation when applying primers and cements and/or soldering materials.
7. Wear protective gloves. PVA-coated protective gloves are recommended when applying solvent cement. If hands contact solvent cement, use a waterless, abrasive soap to remove all residue.
8. When solvent cementing, avoid sources of heat or open flame. DO NOT smoke while handling solvent cement.
9. Keep work areas clean. Cluttered areas and slippery floors can create hazardous working conditions.
10. Wear hearing protection. Protect your hearing if you are exposed to long periods of very noisy job-site operations.
11. Keep visitors away. All visitors should be kept a safe distance away from the work area.
12. Follow all manufacturers' recommended precautions when cutting or sawing pipes, or when using any heat, flame, or power tools.

MODEL CODES

Spears® CPVC products meet ASTM D 2846 requirements, as referenced in the current version of the following model codes.

Code	Organization
BOCA National Plumbing Code	Building Officials and Code Administrators International, Inc.
CABO 1- and 2-Family Dwelling Code	Council of American Building Officials
Canadian Plumbing Code	National Research Council, Canada
International Plumbing Code	BOCA, ICBO, SBCCI
National Standard Plumbing Code	National Association of Plumbing-Heating-Cooling Contractors
Standard Plumbing Code	Southern Building Code Congress International Inc.
Uniform Plumbing Code	International Association of Plumbing and Mechanical Officials

LISTING AGENCIES

Standard	Organization
Standards 14 and 61	NSF International (ANSI/NSF)

HELPFUL INFORMATION - ENGLISH AND METRIC CONVERSION CHART

The following table can be used as a guide for converting measurements listed throughout this manual.

Convert U.S. to Metric		Convert Metric to U.S.	
25.4 X inches (in.)	=	millimeters (mm)	X 0.03937
0.3048 X feet (ft.)	=	meters (m)	X 3.281
0.4536 X pounds (lbs.)	=	kilograms (kg)	X 2.205
28.35 X ounces (oz.)	=	grams (g)	X 0.03527
6.894 X pressure (psi)	=	kilopascals (kPa)	X 0.145
.069 X pressure	=	Bar	X 14.5
4.45 X end load (lbs.)	=	Newtons (N)	X 0.2248
1.358 X torque (ft-lbs)	=	Newton meters (N•m)	X 0.738
F – 32 ÷ 1.8 temp. (° F)	=	Celsius (° C)	C X 1.8 + 32
745.7 X horsepower (hp)	=	watts (W)	X 1.341 X 10 ⁻³
3.785 X gal. per min. (GPM)	=	liters per min. (L/M)	X 0.2642
3.7865 X 10 ⁻³ gal. per min. (GPM)	=	cubic meters per min. (m³/m)	X 264.2

HANDLING AND STORAGE

Spears® CPVC products resist attack from a large group of chemicals that are corrosive to metallic piping. However, care must be taken to avoid contact with chemicals that are harmful to CPVC. Specific chemicals, or chemical vapors, that contact CPVC can weaken or damage the system. Consult with Spears® before using these CPVC products with any questionable materials.

⚠ WARNING

- DO NOT expose Spears® CPVC products to edible oils, esters, ketones, or petroleum-based products, such as: cutting oils; packing oils; traditional pipe thread paste or dopes; and certain lubricants. Consult with Spears® before using certain chemicals with these CPVC products.

Failure to follow this instruction could cause product/system damage, resulting in serious personal injury and/or property damage.

Spears® recommends that CPVC products be stored indoors. If storing outdoors, these products must be covered with a non-transparent material to prevent extended sunlight exposure. Brief exposure to direct sunlight on the job site may result in color fade, but it will not affect the material's physical properties. Spears® CPVC fittings should be stored in their original containers to keep them free from dirt and to help reduce the possibility of damage.

⚠ WARNING

- Spears® CPVC products must not be subjected to prolonged sunlight exposure.
- For outdoor storage, products must be stored in their original shipping containers, or they must be covered with a non-transparent material.

Failure to follow this instruction could cause product/system damage, resulting in serious personal injury and/or property damage.

Reasonable care must be exercised in handling Spears® CPVC products. Do not drop these products or allow anything to drop on them. If improper handling results in scratches, splits, or gouges, the damaged fitting or section of piping must be discarded.

SYSTEM LISTINGS, USAGE, AND STANDARDS

Penetrating Fire-Rated Walls and Partitions

Spears® CPVC products can be used within fire-rated buildings, provided all penetrations of fire barriers are constructed so that the fire rating of the barrier is not compromised. Most codes accept penetration sealing systems or devices that are UL Listed or have passed the appropriate ASTM E 119 or E 814 tests. The PPFA manual, "Plastic Pipe in Fire Restrictive Construction" (NER370), provides more information and lists the applicable test reports. In addition, reference can be made to the current issue of the "Underwriters Laboratories Inc. Directories of Fire Resistance – Vol. II" or the "WHI Certification Listings." Before starting an installation, always consult the building codes and local authority having jurisdiction.

⚠ WARNING

- Some fire-stopping systems contain chemicals that can damage CPVC products. Always consult with Spears® and the fire-stop manufacturer concerning compatibility with CPVC products.

Failure to follow this instruction could cause product/system damage, resulting in serious personal injury and/or property damage.

Underslab Installations

Spears® CPVC products are approved for underslab installations (with joints) in all model-plumbing codes. When performing underslab installations, it is important to support the pipe evenly on a smooth surface. The bedding and backfill should be sand or clean soil that is free from sharp rocks and other debris that could damage the pipe.

Underslab installations that contain joints must be pressure tested before pouring the slab. **NOTE:** IAPMO IS 2098, "Installation Standard for CPVC Solvent Cemented Hot and Cold Water Distribution Systems," requires a test at 150 psi for 2 hours. The pipe should be sleeved where it penetrates the slab, along with construction joints within the slab.

Spears® CPVC products can be used with pipe manufactured in accordance with ASTM D 2846, which is available in coils for underslab installations. When turning coiled piping up through a slab, into walls, etc., make sure the piping does not kink. Sections of pipe that contain kinks must be cut out and replaced.

Freeze Protection/Sunlight Exposure

CPVC piping must be protected from freezing in all installation locations. Attention shall be paid to local insulating techniques and codes that require a particular method. Use only methods and materials suitable for use with CPVC piping. Where freezing is not an issue, CPVC shall not be installed so as to be subject to direct sunlight after installation and not installed on the surface of a building, unless protected by a covering or a chemically compatible paint, such as water based Latex.

Hose Bibb Installation

Hose bibbs are to be connected only to metal system components which are adequately anchored to the building structure. CPVC plastic systems must terminate in the wall.

Water Heater Connections

Before attempting to use Spears® CPVC products in water heater connections, determine if local plumbing codes contain detailed requirements for connections to gas or electric storage-type heaters. **DO NOT** use Spears® CPVC products with commercial-type, non-storage water heaters.

For areas where local plumbing codes do not have requirements, the following information can be used as a guide for water heater connections:



- On electric water heaters, CPVC can be joined directly to the heater, using metal-to-CPVC transition fittings.
- On high-efficiency gas water heaters that use plastic vent piping, CPVC can be joined directly to the heater in the same way as an electric water-heater connection.
- On all other gas water heaters, there should be at least 6" of clearance between the exhaust flue and any CPVC piping. A minimum of 6" metallic pipe should connect directly to the heater so that the CPVC piping cannot be damaged by the buildup of excessive, radiant heat from the flue.
- A temperature/pressure relief valve should be installed so that the sensing element contacts the water at the top of the heater.

- Spears® CPVC products are approved by all model codes for use as relief-valve drain lines. A metal-to-CPVC transition fitting should be used to connect the piping to the relief valve. Then, the piping should be continued to the outlet. Both horizontal and vertical pressure relief drain should be supported every 3 feet.
- For horizontal runs, slope the piping toward the outlet. Support the piping at 3-foot centers or closer. The piping must discharge to the atmosphere at an approved location.
- Instantaneous water heaters (i.e., under sink units) require at least 6" of metallic pipe connected to heater inlet and no CPVC installed down stream.

BASIC JOINT ASSEMBLY

Cutting the Pipe

CPVC piping can be cut easily with a ratchet cutter, wheel-type plastic piping cutter, a power saw, or any other fine-tooth saw.





Be careful not to split the pipe if using a ratchet-type cutter, especially in temperatures below 50° F. If any damage or cracking is evident, cut off at least 2" of the pipe beyond any visible crack.


It is important that the cutting tools being used are designed for plastic piping. To ensure that the pipe is cut square, use a miter box when cutting the pipe with a saw. Cutting the pipe as square as possible provides the maximum bonding surface area.

Deburring

Burrs and filings can prevent contact between the pipe and the fitting during assembly and must be removed from the outside and the inside of the pipe. A chamfering tool or file is suitable for this purpose (refer to photos below).



A slight bevel must be placed at the end of the pipe, as shown below. A slight bevel will ease the entry of the pipe into the socket and minimize the chance of cement being wiped off the fitting.



Fitting Preparation

Using a clean, dry rag, wipe any loose dirt and moisture from the fitting's socket and pipe end. Moisture can slow the cure time, and at this stage of assembly, excessive moisture can reduce joint strength.

⚠ WARNING

- Before assembling any Spears® CPVC products, inspect all components for cuts, scratches, gouges, split ends, or any other irregularities that have occurred during shipping and handling.

Failure to follow this instruction could cause joint/system failure, resulting in serious personal injury and/or property damage.

Check all mating components to ensure that tolerances and engagements are compatible. DO NOT use any components that appear irregular or do not fit properly. Contact Spears® regarding any questions about usability.

Check the dry fit of the pipe and fitting. The pipe should enter the fitting's socket easily 1/4 - 3/4 of the way.

⚠ WARNING

- Always apply a second coat of cement to the pipe for joints that are 1-1/4 inch and larger.

Failure to follow these instruction could cause joint/system failure, resulting in serious personal injury and/or property damage.

SOLVENT CEMENTING PROCEDURES

Verify the expiration date located on the solvent cement container. The cement can be used for a period of 2 years from the date stamped on the container. When cementing pipe and fittings in extremely cold temperatures, make sure the cement has not "JELLED." Jelled or expired cement must be discarded in an environmentally friendly fashion, in accordance with local regulations. To prolong the life of solvent cement, keep the containers tightly closed when not in use, and cover the container as much as possible during use. If an unopened solvent cement container is subjected to freezing temperatures, the cement may become extremely thick. Place the closed container in a room temperature area where, after a short time period, the cement will return to a usable condition. DO NOT attempt to heat solvent cement.

⚠ WARNING

- Before assembling any Spears® CPVC products, verify that the solvent cement is within 2 years of the date stamped on the can and that it does not have a "JELLED" appearance. Jelled or expired solvent cement will not provide the strength needed to make a proper joint.

Failure to follow these instruction could cause joint/system failure, resulting in serious personal injury and/or property damage.


The cement must be applied when the pipes and fittings are clean and free from any moisture and debris.

USING AN APPLICATOR OR NATURAL BRISTLE BRUSH THAT IS AT LEAST 1/2 THE SIZE OF THE PIPE DIAMETER, WORK THE CEMENT INTO THE JOINING SURFACES USING A CONTINUOUS, CIRCULAR MOTION.


Apply the cement in the following sequence, as pictured below:

1. Apply a coat to the pipe
2. Apply a coat to the fitting
3. Apply a second coat to the pipe, if required

Avoid puddling the cement on or within the fitting and pipe. Puddled cement causes excess softening and damage to the CPVC material.



Apply a heavy, even coat of cement to the outside of the pipe end. Work the cement into the joining surfaces using a continuous, circular motion.



Apply a medium coat to the fitting socket. Avoid getting cement in other sockets or threaded connections.

A second application of cement must be applied to the pipe end if a 1-1/4 inch and larger joint is being prepared.


⚠ WARNING

- Always apply a second coat of cement to the pipe for joints that are 1-1/4 inch and larger.
 - Avoid puddling the cement on the pipe or within the fitting.
 - Avoid getting cement into other sockets or threaded connections.
- Failure to follow these instructions could cause joint/system failure, resulting in serious personal injury and/or property damage.

Joint Assembly

Immediately insert the pipe into the fitting's socket while rotating the pipe 1/4 turn. Align the fitting in the proper orientation at this time. Make sure the pipe bottoms out at the fitting's stop.

Hold the assembly for 10 to 15 seconds to ensure initial bonding occurs. A bead of cement must be present around the pipe and fitting juncture. If this bead is not continuous around the socket's shoulder, insufficient cement was applied.



If insufficient cement was applied, the joint must be cut out and discarded, and a new joint must be assembled.

Any cement, in excess of the bead, can be wiped off with a dry, clean rag.

Set and Cure Times

- The set and cure times for CPVC solvent cement depend on pipe size, temperature, relative humidity, and tightness of fit. Drying time is faster for drier environments, smaller pipe sizes, high temperatures, and tighter fits.
- Special care must be taken when assembling Spears® CPVC products in low temperatures (below 40° F) or high temperatures (above 80° F).
- Extra set and handling times must be allowed in colder temperatures. When cementing pipe and fittings in cold temperatures, make sure the cement has not "JELLED." Jelled cement must be discarded.
- In higher temperatures, make sure both surfaces to be joined are still wet with cement during assembly.
- The assembly must be allowed to set, without any stress on the joint, for 5 minutes.
- Following the initial set period, the assembly can be handled carefully by avoiding stress on the joint.

Refer to the following table for minimum cure times before pressure testing.

MINIMUM CURE TIMES FOR SOLVENT CEMENT BEFORE PRESSURE TESTING

150-psi Maximum Test Pressure

Piping Size	Ambient Temperature During Cure (Relative Humidity 60% or Less)		
	60° F to 100° F	40° F to 60° F	0° F to 40° F
Nominal Diameter inches			
1/2	15 minutes	20 minutes	30 minutes
3/4	15 minutes	20 minutes	30 minutes
1	15 minutes	20 minutes	30 minutes
1-1/4	15 minutes	20 minutes	30 minutes
1-1/2	30 minutes	45 minutes	1 hour
2	30 minutes	45 minutes	1 hour

⚠ WARNING

- Make sure the cement is allowed to cure, according to the times listed in the chart, for the pipe size and ambient temperature.

Failure to follow this instruction could cause joint/system failure, resulting in serious personal injury and/or property damage.

TRANSITION JOINTS AND FITTINGS

CPVC pipe can be connected to copper, brass, valves, and other materials using a variety of transition fittings including unions, compression fittings, specially reinforced male and female adapters, flanged joints, grooved joints and other readily available transition fittings.

Do not thread CPVC pipe and do not use regular CPVC female threaded fittings. Regular CPVC male threaded fittings shall only be used on cold water applications. Spears® Special Reinforced Male Adapters, CPVC Lined Brass-Threaded Male Adapters, Special Reinforced Female Adapters and Gasket Sealed Brass-Threaded Female Adapters are recommended for hot water applications and threaded transitions to metal pipe. All approved threaded CPVC joints must be accessible. (See also Water Heater Connections section for additional installation details.)

Standard compression fittings with brass ferrules can be used; however, PTFE tape must be applied over the brass ferrule to compensate for the dissimilar thermal expansion rates between the brass and CPVC. Caution must be exercised to prevent over tightening of compression fittings. Use extreme care when soldering any metal system to prevent flame contact with or heat distortion in CPVC pipe and fittings.

Assembling Gasket Sealed Brass-Threaded Female Adapter Connections

Threaded connections using Spears® Gasket Sealed Brass-Threaded Female Adapters with O-ring seal at the base of the fitting thread are designed to be assembled without thread sealants. DO NOT use ANY thread sealants, tape or paste, in these joints. Thread hand tight and tighten snug. This produces a leak-free, reliable seal without problems associated with incompatible thread pastes or improperly applied tape (TFE) sealants.

⚠ WARNING

- DO NOT use ANY thread sealants on Gasket Sealed Brass-Threaded Female Adapter. Sealants, especially tape (TFE), may prevent proper joint make-up and result in leaks.
- DO NOT over tighten. Wrench over tightening of joints may result in fitting damage.



Assembling Standard Threaded Connections

Threaded connections using standard tapered threads (including Spears® Special Reinforced Female Adapters, Special Reinforced Male Adapters, Brass-Threaded and Regular Male Adapters) require the application of a thread sealant that is compatible with CPVC material. Spears® recommends the use of Spears® Blue 75 Thread Sealant. DO NOT use ANY thread sealants on Spears® Gasket Sealed Brass-Threaded Female Adapters (see above).

⚠ WARNING

- Use only thread sealants recommended by Spears®. Other joint compounds or pastes may contain substances that could cause stress cracks in CPVC or brass materials.

Failure to follow these instructions could cause joint/system failure, resulting in serious personal injury and/or property damage.

Apply sealant to the male threads only. Make sure all threads are covered. DO NOT clog the waterway with excess sealant.

If PTFE tape is used, Spears® recommends a thickness of at least .0025" that meets or exceeds military specification, MIL-T-27730A. DO NOT use a combination of tape and thread sealant on the same joint.

Apply PTFE tape in the direction of the threads by starting with the first full thread and continuing over the entire thread length. Make sure all threads are covered. Generally, 2 - 3 wraps are sufficient to produce a watertight connection.

⚠ WARNING

- DO NOT use more than five wraps of PTFE tape. Excessive tape can cause bunching, resulting in fractures of the plastic fitting or the brass insert due to excessive hoop stress.

Failure to follow these instructions could cause joint/system failure, resulting in serious personal injury and/or property damage.

DO NOT over-torque any threaded connections. Generally, one to two turns beyond finger-tight are required for a threaded connection. Factory testing has indicated that 10 - 25 ft-lbs of torque is adequate to obtain a leak-free seal. Use only a smooth-jawed wrench or strap wrench when installing threaded connections.

⚠ WARNING

- Tools with teeth **MUST NEVER** be applied to any part of a CPVC fitting. The teeth can damage and weaken CPVC material.

Failure to follow these instructions could cause joint/system failure, resulting in serious personal injury and/or property damage.

ENGINEERING DATA SECTION

Pipe and Fitting Specifications

CPVC pipe is produced in SDR 11 dimensions using copper pipe size (CTS) outside diameters, as specified in ASTM D 2846. Spears® fittings are produced in SDR 11 dimensions, in accordance with ASTM D 2846. The combined pipe and fitting system is NSF listed for potable water. In addition, the system meets test requirements of the Uniform Building Code.

CPVC Piping Dimensions

SDR 11 (Ref. ASTM D 2846)			Weight lbs/ft
Size Nominal inches	Average OD inches	Average ID inches	
1/2	0.625	0.469	.090
3/4	0.875	0.695	.149
1	1.125	0.901	.240
1-1/4	1.375	1.105	.353
1-1/2	1.625	1.309	.489
2	2.125	1.716	.829

Pressure Ratings

The Spears® CPVC system, including the joint, has a continuous rated working pressure of 100 psi at 180° F or 400 psi at 73° F. CPVC systems have the capability to withstand short-term temperature/pressure increases above 100 psi at 180° F, as evidenced by their ability to consistently surpass the 48 hour, 150 psi Uniform Building Code test at 210° F. CPVC pipe should not be used where temperatures will consistently exceed 180° F.

Pressure-Temperature De-Rating Factors
For CTS CPVC 4120 SDR 11 Piping Systems

° F	Factor	Rating, PSI
73	1.00	400
80	1.00	400
90	0.91	360
100	0.82	325
120	0.65	260
140	0.50	200
160	0.40	160
180	0.25	100

The pressure de-rating factor is the same for all pipe sizes.

Example: Determine the maximum allowable operating pressure for a CTS CPVC piping system with an operating temperature of 140° F. Using de-rating factor of 0.50 for 140° from the above chart, the maximum allowable operating pressure = 400 x 0.50 = 200 psi.

Hydraulic Design

Friction Loss – Friction loss through CPVC pipe is most commonly obtained by the use of the Hazen-Williams equations as expressed below for water:

$$f = .2083 \times \frac{(100)^{1.852}}{C} \times \frac{G^{1.852}}{d_i^{4.8655}}$$

where:

f = friction head of feet of water per 100' for the specific pipe size and I.D.

C = a constant for internal pipe roughness. 150 is the commonly accepted value for CPVC pipe.

G = flow rate of gallons per minute (U.S. gallons).

d_i = inside diameter of pipe in inches.

Compared to other materials on construction for pipe, thermoplastic pipe smoothness remains relatively constant throughout its service life.

Flow Velocities – Velocities for water in feet per second at different GPM's and pipe inside diameters can be calculated as follows:

$$V = .3208 \frac{G}{A}$$

where:

V = velocity in feet per second

G = gallons per minute

A = inside cross sectional area in square inches

While these systems can operate with flow velocities in excess of 10 feet per second, a maximum of 8 feet per second velocity is recommended to extend system life.

The following table lists Friction Loss and Flow Velocities for SDR 11 CTS CPVC Pipe at different flow rates.

FRICION LOSS AND FLOW VELOCITY FOR SDR 11 CTS CPVC PIPE

Friction head and friction loss are per 100 feet of pipe.

Gallons Per Minute	Velocity Feet Per Second	Head Loss Feet of Water Per 100 Ft.	Pressure Loss PSI Per 100 Ft.	1 in.				1-1/4 in.				1-1/2 in.				2 in.			
1	1.71	3.19	1.38	0.48	0.15	0.06		3.23	3.94	1.71	2.31	1.75	0.76	1.35	0.49	0.21			
2	3.42	11.53	5.00	0.96	0.53	0.23		4.84	8.35	3.62	3.47	3.71	1.61	2.03	1.03	0.45			
3	5.13	24.43	10.59	1.44	1.12	0.49		6.46	14.23	6.17	4.63	6.33	2.74	2.70	1.76	0.76			
4	6.83	41.62	18.04	1.93	1.91	0.83		8.07	21.51	9.33	5.78	9.56	4.15	3.38	2.66	1.15			
5	8.54	62.91	27.27	2.41	2.89	1.25		9.68	30.15	13.07	6.94	13.40	5.81	4.05	3.73	1.62			
6	10.25	88.12	38.23	2.89	4.05	1.76		11.30	40.11	17.39	8.09	17.83	7.73	4.73	4.96	2.15			
7	11.96	117.32	50.86	3.37	5.39	2.34		12.91	51.37	22.27	9.25	22.83	9.90	5.40	6.35	2.75			
8	13.67	150.23	65.13	3.85	6.90	2.99		14.52	63.89	27.70	10.41	28.40	12.31	6.08	7.89	3.42			
9	15.38	186.85	81.00	4.33	8.58	3.72		16.14	77.66	33.66	11.56	34.52	14.96	6.75	9.60	4.16			
10	17.08	227.11	98.45	4.82	10.43	4.52		17.75	92.65	40.16	12.72	41.18	17.85	7.43	11.45	4.96			
15				7.22	22.11	9.58		18.86			13.88	48.38	20.97	8.10	13.45	5.83			
20				9.63	37.67	16.33					16.19	64.37	27.90	9.46	17.89	7.76			
25				12.04	56.94	24.69								10.61	22.91	9.93			
30				14.45	79.82	34.60								12.16	28.50	12.35			
35				16.86	106.19	46.03								13.51	34.64	15.02			
40														16.89	52.37	22.70			
45																			
50																			
55																			
60																			
70																			
80																			
90																			
100																			
125																			

Hanger/Support Spacing

Since CPVC pipe is rigid, it requires fewer supports than flexible, plastic systems.

Vertical runs should be supported at each level so that the weight of the run is not placed on a fitting or a joint.

Horizontal runs require support every 3 feet for 1/2" - 1" diameter pipe and every 4 feet for 1-1/4" and larger diameters. Support spacing should be in accordance with applicable local codes.

Horizontal runs must be braced so that the stress loads (caused by bending or snaking) will not be placed on a fitting or a joint. Hanger support spacing information is shown in Table A.

Spears® recommends that hangers, designed for supporting CPVC, be used to support CPVC piping. However, some hangers, designed for steel pipe, may be used if their suitability is clearly established. These hangers must be selected to accommodate the specific pipe size. In addition, they cannot contain rough or sharp edges that contact the pipe, and they must not bind the pipe from axial movement that is caused by expansion and contraction.

Table A - Hangers and Supports
Reference CPVC ASTM D 2846 Systems

Pipe Size (CTS) Nominal inches	Maximum Support Spacing Feet	Water-filled Weight lbs/ft
1/2	3	0.153
3/4	3	0.294
1	3	0.486
1-1/4	4	0.726
1-1/2	4	1.014
2	4	1.733

WARNING

Horizontal runs and vertical risers of CPVC piping require additional support and provision for expansion and contraction, compared to metal piping systems. Systems must be designed and installed by qualified personnel, in accordance with the properties and capabilities of the material.

Failure to follow these instructions could cause joint or system failure, resulting in serious personal injury and/or property damage.

Material Properties

Table I
Modulus of Elasticity and Stress vs. Temperature

Property	Temperature ° F							
	73	80	90	100	110	120	140	150
Modulus of Elasticity "E" × 10 ⁵ psi	3.900	3.840	3.780	3.700	3.460	3.210	3.050	2.840
Working Stress "S" psi	1900	1785	1630	1485	1345	1270	950	875

Table II
Physical and Thermal Properties

Property		CPVC	ASTM
Specific Gravity	"Sp. Gr."	1.51	D 792
IZOD Impact Strength (ft-lbs/inch of notch)		5.0	D 256A
Modulus of Elasticity, psi	"E"	3.9 × 10 ⁵	D 638
Ultimate Tensile Strength, psi		8,000	D 638
Compressive Strength, psi	"σ"	9,000	D 695
Poisson's Ratio	"ν"	.35 - .38	—
Working Stress @ 73° F, psi	"S"	1,900	D 1598
Hazen-Williams "C" Factor	"C"	150	—
Coefficient of Linear Expansion in/(in ° F)	"e"	3.2 × 10 ⁻⁵	D 696
Thermal Conductivity BTU/(hr ° F ft/in ²)	"k"	0.95	C 177
Upper Temperature Limit	"° F"	205	
Flammability		Flame Retardant	
Electrical Conductivity		Non-Conductor	


Expansion and Contraction

⚠ WARNING

Horizontal runs and vertical risers of CPVC piping require additional support and provision for expansion and contraction, compared to metal piping systems. Systems must be designed and installed by qualified personnel, in accordance with the properties and capabilities of the material.

Failure to follow these instructions could cause joint or system failure, resulting in serious personal injury and/or property damage.

Expansion Loop Offset Configurations



CPVC, like all piping materials, expands and contracts with changes in temperature. The coefficient of linear expansion for CPVC is 3.2×10^{-5} in./in./° F. A 25° F change in temperature will cause an expansion of 1" for a 100-ft straight length. For most installation and operating conditions, expansion and contraction can be accommodated at changes of direction. Based on the following chart, an offset or loop is required on a long, straight run.

Table III: Thermal Expansion in inches

Temp Change ΔT ° F	Length of Run in feet													
	5	10	15	20	25	30	35	40	45	50	70	90	120	160
	Thermal Expansion ΔL (inches)													
20	0.04	0.08	0.12	0.15	0.19	0.23	0.27	0.31	0.35	0.38	0.54	0.69	0.92	1.23
30	0.06	0.12	0.17	0.23	0.29	0.35	0.40	0.46	0.52	0.58	0.81	1.04	1.38	1.84
40	0.08	0.15	0.23	0.31	0.38	0.46	0.54	0.61	0.69	0.77	1.08	1.38	1.84	2.46
50	0.10	0.19	0.29	0.38	0.48	0.58	0.67	0.77	0.86	0.96	1.34	1.73	2.30	3.07
60	0.12	0.23	0.35	0.46	0.58	0.69	0.81	0.92	1.04	1.15	1.61	2.07	2.76	3.69
70	0.13	0.27	0.40	0.54	0.67	0.81	0.94	1.08	1.21	1.34	1.88	2.42	3.23	4.30
80	0.15	0.31	0.46	0.61	0.77	0.92	1.08	1.23	1.38	1.54	2.15	2.76	3.69	4.92
90	0.17	0.35	0.52	0.69	0.86	1.04	1.21	1.38	1.56	1.73	2.42	3.11	4.15	5.53
100	0.19	0.38	0.58	0.77	0.96	1.15	1.34	1.54	1.73	1.92	2.69	3.46	4.61	6.14

$\Delta L = 12 e l (\Delta T)$

$e = 3.2 \times 10^{-5}$ in./in./° F (Coefficient of Linear Expansion – Table II)

L = Length of Run in feet

ΔT = Temperature Change in ° F

Example: How much will a 40-ft run of 2" CPVC pipe expand if the expected ambient temperature will range from 45° F to 85° F?
 $\Delta L = 12 e l (\Delta T)$
 $\Delta L = 12 (.000032) \times 40 \times 40$
 $\Delta L = .61"$

Table IV: Expansion Loop Length in inches

Nominal Pipe Size	Avg. O.D.	Length of Run in feet													
		5	10	15	20	25	30	35	40	45	50	70	90	120	160
		Length of Loop (inches) Temperature Change (ΔT) = 100° F - 30° F = 70° F													
1/2	0.625	6	8	10	11	13	14	15	16	17	18	21	24	27	32
3/4	0.875	7	9	11	13	15	16	18	19	20	21	25	28	32	38
1	1.125	8	11	13	15	17	18	20	21	23	24	28	32	37	43
1-1/4	1.375	8	12	14	17	19	20	22	24	25	26	31	35	41	47
1-1/2	1.625	9	13	16	18	20	22	24	26	27	29	34	38	44	51
2	2.125	10	15	18	21	23	25	27	29	31	33	39	44	51	58

Note: Table IV is based on 70° F temperature change. Values rounded.

$$l = \sqrt{\frac{3 E D (\Delta L)}{2 S}}$$

l = Length of Expansion Loop in inches

E = Modulus of Elasticity at 100° F (Table I)

D = Average OD of Pipe

ΔL = Change in Length of Pipe Due to Change in Temperature (Table III)

S = Working Stress at 100° F (Table I)

Example: How much expansion can be expected in a 200-ft run of 2" CPVC pipe? How long should the expansion loop be to compensate for the expansion (the expected temperature range will be from 40° F to 110° F)?

First Find:

$\Delta T = (\text{Change in Temperature})$

$\Delta T = T_2 - T_1$

$\Delta T = 110^\circ \text{ F} - 40^\circ \text{ F}$

$\Delta T = 70^\circ \text{ F}$

To Find

$\Delta L = (\text{Amount of Expansion in inches from Table III})$

$\Delta L = \Delta L \text{ of } 160 \text{ ft with a } \Delta T \text{ of } 70^\circ \text{ F} + \Delta L \text{ of } 40 \text{ ft. with a } \Delta T \text{ of } 70^\circ \text{ F}$

$\Delta L = 4.30" + 1.08"$

$\Delta L = 5.38"$

— OR —

$\Delta L = 12 e L (\Delta T)$

$e = 3.2 \times 10^{-5}$ (from Table II)

$L = \text{Length of Run in Feet}$

$\Delta T = \text{Change in Temperature in } ^\circ \text{ F}$

$\Delta L = 12 \times 0.00032 \times 200 \times 70$

$\Delta L = 5.38"$

$$I = \sqrt{\frac{3ED(\Delta L)}{2S}}$$

$I = \text{Length of Expansion Loop in inches}$

$E = \text{Modulus of Elasticity at } 110^\circ \text{ F (Refer to Table I)}$

$D = \text{Average OD of Pipe}$

$\Delta L = \text{Change in Length of Pipe Due to Change in Temperature}$

$S = \text{Working Stress at } 110^\circ \text{ F (Refer to Table I)}$

To find the length of the expansion loop or offset in inches:

$$I = \sqrt{\frac{3ED(\Delta L)}{2S}}$$

$I = \text{Length of Expansion Loop in inches}$

$E = \text{Modulus of Elasticity at Maximum Temperature from Table I}$

$D = \text{Average Outside Diameter of the Pipe from Table IV}$

$S = \text{Working Stress at Maximum Temperature from Table I}$

$\Delta L = \text{Change in Length of Pipe Due to Change in Temperature from Table III}$

$$I = \sqrt{\frac{3 \cdot 346,000 \cdot 2.125 \times 5.38}{2 \times 1345}}$$

$$I = \sqrt{4412}$$

$$I = 66.4$$

CPVC Piping System Guidelines for Commercial Hot & Cold Water Distribution Applications

EverTUFF® CPVC Systems provide highly sustainable, cost effective alternatives to metal piping in commercial multi-story applications for hot and cold water distribution. EverTUFF® CPVC pipe and fittings are available for most any size project using Copper Tube Size (CTS) CPVC in sizes 1/2" through 2" and in supplemental Schedule 40 and Schedule 80 CPVC Iron Pipe Size (IPS) for sizes 2-1/2" through 12".

EverTUFF® CPVC Systems meet applicable code requirements and are fully suitable for use in multi-story installations where adequate design and installation practices have been utilized. The following overview includes, but is not limited to, general considerations that *must* be addressed in all CPVC system designs and installations.

WARNING: Failure to follow proper industry established design and installation practices and requirements for CPVC systems may result in system failure, severe personal injury and/or property damage. The following are general guidelines for issues that must be addressed with use of CPVC in commercial water distribution systems. All design criteria applicable to thermoplastics should be reviewed and approved by a licensed engineering professional.

Product Capability & Ratings

EverTUFF® CPVC CTS piping is produced in Standard Dimensional Ratio (SDR) of 11, where the ratio of wall thickness to outside diameter of the pipe is a constant of 11. This produces the same pressure rating for all sizes.

Available Sizes: 1/2", 3/4", 1", 1-1/4", 1-1/2", 2"

Pressure Rating: 100 psi @ 180° F

Applicable Standard: ASTM D 2846 for CPVC Copper Tube Size (CTS) Hot & Cold Water Distribution Systems

Potable Water Certification: ANSI/NSF Standard 61

EverTUFF® Industrial CPVC IPS piping produced in Schedule 40 or Schedule 80 dimensions can be used for larger pipe sizes. Pressure ratings will vary according to diameter and water temperature. The appropriate Schedule piping (40 or 80) must be selected according to application and system requirements.

Supplemental Available Sizes: 2-1/2", 3", 4", 6", 8", 10", 12"

Pressure Ratings: According to pipe size and temperature; specified in ASTM F 441

Applicable Standard: Pipe - ASTM F 441 for CPVC Schedule 40 & Schedule 80 Pipe
Fittings - ASTM F 439 for CPVC Schedule 80 Fittings

Potable Water Certification: ANSI/NSF Standard 61

Piping Support & Spacing

Hanger and support spacing for horizontal runs of Spears® EverTUFF® CPVC piping varies according to pipe diameter and water temperature. Local code requirements generally affect minimum spacing for CPVC piping and must be verified. Additional support should be provided for valves, flanges, expansion joints or other sources of load concentration. Hangers and straps designed for CPVC should be used, but some hangers designed for steel pipe can be used if suitable. Use only smooth straps or hangers that do not place rough or sharp edges against the pipe. Do not anchor CPVC piping too tight to supports in order to allow movement caused by expansion and contraction, bind or restrict movement.

Vertical runs (risers) must be properly supported to prevent excessive loading on the lower fitting or other stress concentration areas. Maintain vertical piping in straight alignment with supports at each floor level, or at 10 feet (3.05 m) intervals, whichever is less. Hangers and clamps suitable for this purpose include riser clamps or double bolt type clamps that provide a floating system which allows pipe movement due to thermal expansion and contraction when installed. Clamps and hangers must not compress, distort, cut, abrade or exert compressive stresses on the pipe; the use of riser clamps that utilize compression to support the pipe weight are not recommended.

Wall Penetration

Where Spears® EverTUFF® CPVC pipe passes through metal studs, protection must be used to prevent abrasion and reduce noise. Plastic insulators, rubber grommets, pipe insulation or similar devices may be used for this purpose.

Where penetrations of fire barriers are required, Spears® EverTUFF® CPVC piping can be used with Fire-Stop penetration sealing systems approved for use with CPVC. Most codes accept penetration sealing systems or devices that are UL Listed or have passed the appropriate ASTM E 119 or E 84 tests. Before starting an installation, always consult the building codes and local authority having jurisdiction.

Thermal Expansion & Contraction

Expansion and contraction in CPVC thermoplastic systems differs significantly from that of metal systems and can result in major problems if not adequately considered. Spears® EverTUFF® CPVC piping will expand or contract about 1 inch per 50 feet of length with a 50-degree temperature change. This movement must be accommodated in system design or else a system can literally push or pull itself apart. Thermal expansion is a primary concern in hot water lines.

Expansion and contraction expectations must be calculated according to standard industry practices. For most installation and operating conditions, movement accommodation can be made at system changes of direction, through use of telescoping expansion joints, an offset or loop on a long straight runs. Telescoping expansion joint needs must be properly calculated and the telescoping units properly aligned and installed. While only one properly sized expansion loop is required in any straight run, two or more properly sized smaller expansion loops can be used to conserve space as required.

Hydraulic Design

Spears® EverTUFF® CPVC piping systems must be sized based on industry standard hydraulic calculations for factors such as friction loss and flow velocity. Surge protection must also be considered.

Friction loss through CPVC pipe is typically determined by the use of the Hazen-Williams equations with a C Factor (internal roughness) of 150. Friction loss and flow velocity tables are also available for both CTS CPVC and Schedule 40 or Schedule 80 IPS CPVC piping.

While hot and cold water CTS CPVC systems can operate with flow velocities of 8 feet per second. A maximum velocity of 5 feet per second is recommended for Schedule 40 or Schedule 80 IPS CPVC systems. System flow velocity should always be maintained close to 5 feet per second in mixed CTS/IPS CPVC systems. Hydraulic designs, and value engineered changes should always be reviewed by a licensed engineering professional.

System Connections

Proper system connections are critical to maintaining system integrity and reliability. It is essential that all installation personnel be thoroughly trained in joining methods.

Solvent Cement Joints are the primary method of making connections between CPVC components. Solvent cements specifically approved to ASTM F 493 for CPVC and for use with ASTM D 2846 systems should be used on CTS CPVC installations. ASTM Standards permit the use of "One-step" (primerless) cements; however, local codes must be checked since some require use of both a primer and cement in CPVC joints. Larger Schedule 40 or Schedule 80 IPS joints should be made using an ASTM F 493 approved CPVC cement and primer. Manufacturer's instructions for cement/primer application, initial set times and applicable cure time in accordance with pipe size and temperature must be followed. Proper sized cement applicators should always be utilized (i.e., no less than 1/2 the pipe diameter). On 6" and larger IPS pipe come-alongs or other mechanical helpers are recommended to assist in joint assembly.

Threaded Transitions to metal systems must be made with appropriate fittings designed for plastic-to-metal connections. Spears® offers a variety of transition fittings including metal threaded adapter and the superior Special Reinforced (SR) Female Plastic Thread fittings for the best transition joints.

The chemical compatibility of any thread sealant, pastes, or lubricants with CPVC must be verified. Spears® recommends the use of Spears® Blue 75™ Thread Sealant that has been tested for compatibility. If TFE (Teflon®) sealant tape is used, it must be selected and applied correctly, according to manufacturer's instructions.

Flanged Connection can be used when properly assembled; a full-faced 1/8" thick elastomer gasket must be used. Flange alignment and system support is critical to prevent adverse stress loads. Flange bolts must NEVER be used to draw a flanged system connection together. Flange bolts, nuts, and washers must be properly selected and incrementally tightened in sequence to torque according to flange manufacturer's specifications. Thermoplastic flanges are typically rated at 150 psi for water at 73° F and must be de-rated for systems operating at elevated temperatures (i.e., hot water lines).

Hot Water Heater & Boiler Connections

Connection of CPVC CTS systems to hot water heaters must be made in accordance with code requirements. Typically, 6" metal nipples are required for direct connection to tanks, but approved CPVC CTS piping can be used for connection to temperature/pressure relief valves.

Schedule 80 IPS CPVC Boiler Connections generally *should not* be made directly to the boiler. Most boilers do not have suitable temperature variation control. Connections must assure that the temperature-pressure does not exceed the capability of the CPVC material.

System Pressure Testing

Hydrostatic pressure testing should commence only after all set and cure times for solvent cemented joints have been satisfied. The system should be pressure tested in accordance with local code requirements following industry accepted practices for thermoplastic systems.

Under slab installations that contain joints must be pressure tested before pouring the slab. NOTE: IAPMO IS 2098, "Installation Standard for CPVC Solvent Cemented Hot and Cold Water Distribution Systems," requires a test at 150 psi for 2 hours.

In freezing temperatures the system should be adequately purged of water after testing to avoid damage from freezing.



Spears® Manufacturing Company CPVC CTS PRODUCT LIMITED LIFETIME WARRANTY

Except as otherwise specified for certain products, mandated by law or herein provided, Spears® Manufacturing Company ("Company") warrants Standard Catalog Products ("Products") which have been directly manufactured by them to be free from defects in material and workmanship for as long as the original intended end user of the Products ("End User") retains ownership and possession of the Products and complies with this Warranty ("Warranty Period"). Each other person or entity acquiring or employing the Products, including buyers, contractors and installers ("Buyer") and End Users ("Buyer/End User") agrees that this Warranty shall be effective only during the Warranty Period so long as the Products are used solely for the normal purposes for which they are intended and in conformance with industry established standards, engineering, installation, operating, and maintenance specifications, recommendations and instructions including explicit instructions by the Company; the Products are properly installed, operated and used, and have not been modified; and all the other terms of this Warranty are complied with. Any violation thereof shall void this Warranty and relieve Company from all obligations arising from this Warranty and the Products.

Upon receipt or discovery of any Products that appear questionable or defective each Buyer/End User shall promptly inspect and return any such Product to the Company at 15853 Olden Street, Sylmar, California 91342, accompanied by a letter stating the nature of any problems. If the Products are determined by Company to be defective in materials or workmanship directly provided by Company, Company, at its sole option, may either repair or replace the defective Products, or reimburse applicable Buyer/End User for the cost of such Products. The applicable Buyer/End User shall bear all applicable shipping costs. THIS SHALL BE BUYERS/END USERS' SOLE REMEDY. EACH BUYER/END USER AGREES THAT COMPANY WILL NOT BE RESPONSIBLE FOR ANY OTHER OBLIGATIONS RELATING TO THE PRODUCTS, INCLUDING ANY OTHER MATERIALS OR LABOR COSTS, LOSS OF USE OR ANY OTHER ITEM OR FOR ANY DELAYS IN COMPLYING WITH THIS WARRANTY BEYOND COMPANY'S REASONABLE CONTROL.

COMPANY SHALL NOT BE LIABLE FOR, DOES NOT ASSUME, AND EXPRESSLY DISCLAIMS, ANY LIABILITY, RESPONSIBILITY AND DAMAGES: DUE TO ANY BUYER/END USER'S FAILURE TO COMPLY WITH THIS WARRANTY, INCLUDING IMPROPER INSTALLATION, USE OR OPERATION; USE WITH PRODUCTS FROM OTHER MANUFACTURERS THAT DO NOT MEET ASTM OR OTHER APPLICABLE PRODUCT STANDARDS; IMPROPER CONTROL OF SYSTEM HYDRAULICS, IMPROPER WINTERIZATION PROCEDURES, IMPROPER VOLTAGE SUPPLY, CONTACT WITH INCOMPATIBLE MATERIALS OR CHEMICALS, EXCAVATION/DIGGING, EXCESSIVE WEIGHT, AND VANDALISM; DUE TO REASONABLE WEAR AND TEAR AND DUE TO ANY ACTS OF NATURE, INCLUDING LIGHTNING, EARTHQUAKES, GROUND MOVEMENT, FROST HEAVE, OR FLOODS.

COMPANY EXTENDS ONLY THIS WARRANTY AND EXPLICITLY DISCLAIMS ALL OTHER WARRANTIES, WHETHER IMPLIED OR OTHERWISE EXPRESSED, WHETHER ORAL, STATUTORY OR OTHERWISE, INCLUDING ANY IMPLIED WARRANTIES OR AFFIRMATIONS FOR SUITABILITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. NO AFFIRMATION BY COMPANY OR ANY OF ITS REPRESENTATIVES, BY WORDS, CONDUCT OR OTHERWISE, SHALL CONSTITUTE A WARRANTY. THIS WARRANTY MAY NOT BE TRANSFERRED, EXTENDED, ALTERED OR OTHERWISE MODIFIED IN ANY MANNER, EXCEPT BY WRITTEN AGREEMENT SIGNED BY COMPANY.

BY ITS ACCEPTANCE OF THE PRODUCTS, EACH BUYER/END USER EXPRESSLY WAIVES ALL OTHER LIABILITY OR OBLIGATION OF ANY KIND OR CHARACTER OF COMPANY, INCLUDING LIABILITY PREDICATED UPON CONTRACT, TORT, STRICT LIABILITY OR OTHER LEGAL OR EQUITABLE GROUNDS, AND ALL, IF ANY, DAMAGES AND LOSSES AS A RESULT THEREOF, INCLUDING ALL, IF ANY, COMPENSATORY, GENERAL, SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR PUNITIVE DAMAGES. WITH RESPECT TO SUCH WAIVERS, EACH BUYER/END USER EXPLICITLY WAIVES CALIFORNIA CIVIL CODE §1542 WHICH STATES "A GENERAL RELEASE DOES NOT EXTEND TO CLAIMS WHICH THE CREDITOR DOES NOT KNOW OR SUSPECT TO EXIST IN HIS FAVOR AT THE TIME OF EXECUTING THIS RELEASE, WHICH IF KNOWN BY HIM MUST HAVE MATERIALLY ADVERSELY AFFECTED HIS SETTLEMENT WITH DEBTOR" AND ALL OTHER SIMILAR STATUTORY, COMMON AND CASE LAW RIGHTS, DEFENSES AND LIMITATIONS.

Having previously independently inspected the Products, or a sample, as fully as desired, or having the opportunity to and having not done so, upon acceptance of delivery of the Products, and except as otherwise herein explicitly provided, each Buyer/End User by acceptance or use of the Products accepts them in their "AS IS" and "WITH ALL FAULTS" condition without any other warranty, expressed, implied or otherwise, and accepts and assumes the entire risk and cost of all servicing, remediation and consequences thereof. This Warranty shall be governed by California law and any unenforceable provisions severed without affecting the remaining provisions. As used herein, "including" includes "without limitation."



SPEARS® MANUFACTURING COMPANY • CORPORATE OFFICE

15853 Olden St., Sylmar, CA 91342 • PO Box 9203, Sylmar, CA 91392
(818) 364-1611 • www.spearsmfg.com

