

INSTALLATION: NON FIRE-RATED FIRE EXTINGUISHER CABINET

PAGE 1 OF 1

SLIDING PLEXIGLASS FRONT MODELS

1. If equipped with lock, unlock cabinet and slide plexiglass front out from the top.

2. SURFACE MOUNT: Place cabinet in position level to floor, and mark location of attachments on studding using 3/16" (5mm) holes as marking guides.

RECESSED: Frame in above, below and at both sides of the cabinet opening. **Note:** On load bearing walls, the studs must be doubled on either side of the cabinet tub. If a stud must be cut to install the cabinet, a load bearing header must be installed above the cabinet tub.

3. Remove cabinet and drill 5/32" (4mm) holes through studs at marked points. Install plastic wall anchors. For masonry walls, install expansion shields in wall at marked points.

4. Place cabinet in position and attach with Universal #10 x 2 1/2" (64mm) self-drilling screws.

5. Remove protective plastic from plexiglass and install decal if included.

6. Place fire extinguisher in cabinet

7. Insert plexiglass.

8. If provided, attach chain to hammer and attach to cabinet as indicated.

Lock cabinet if lock provided.

HINGED DOOR MODELS - SURFACE-MOUNTED

1. Remove all hardware and glazing, unlock cabinet if lock provided.

2. Place cabinet in position level to floor, and mark location of attachments on studding using 3/16" (5mm) holes as marking guides.

3. Remove cabinet and drill 5/32" (4mm) holes through studs at marked points. Install plastic wall anchors. For masonry walls, install expansion shields in wall at marked points.

4. Place cabinet in position and attach with Universal #10 x 2 1/2" (64mm) self-drilling screws, or for masonry, appropriate screws for expansion shield.

5. Remove protective plastic from plexiglass or glass and install decal if intended for glass. (Panorama Models Glazing is Pre-Installed)

6. Align glazing on inside of door, holding in place while installing glass mounting clips on inside of door. Do not over-tighten.

7. Install handle and roller catch or SAF-T-LOK™ in door.

8. Place fire extinguisher in cabinet

9. If provided, attach chain to hammer and attach to cabinet as indicated. Lock cabinet if lock provided.

HINGED DOOR MODELS - RECESSED

1. Remove all hardware and glazing, unlock cabinet if lock provided.

2. Frame in above, below and at both sides of the cabinet opening. **Note:** On load bearing walls, the studs must be doubled on either side of the cabinet tub. If a stud must be cut to install the cabinet, a load bearing header must be installed above the cabinet tub.

3. Place cabinet in position and mark location of attachments on studding using 3/16" (5mm) holes as marking guides.

4. Remove cabinet and drill 5/32" (4mm) holes through studs at marked points. install plastic wall anchors.

5. Place cabinet in position and attach with Universal #10 x 2 1/2" (64mm) self-drilling screws. For masonry walls, install expansion shields in wall at marked points.

6. Remove protective plastic from plexiglass or glass and install decal if intended for glass. (Panorama Models Glazing is Pre-Installed)

7. Align glazing on inside of door, holding in place while installing glass mounting clips on inside of door. Do not over-tighten.

8. Install handle and roller catch or SAF-T-LOK™ in door.

9. Check cabinet door assembly for freedom of movement. If it binds, shim as necessary to remove any racking of tub attachments or studding

10. Place fire extinguisher in cabinet

If provided, attach chain to hammer and attach to cabinet as indicated. Lock cabinet if lock provided.



JL INDUSTRIES

ACTIVAR
INC.

www.activarcp.com

Construction Products Group

INSTALLATION - NON FIRE-RATED FIRE EXTINGUISHER CABINET

HEADQUARTERS & CUSTOMER SERVICE: 4450 WEST 78TH ST CIRCLE, BLOOMINGTON, MN 55435-5416 PH: 800-554-6077 FAX: 952-835-2218 EMAIL: SALES@JLINDUSTRIES.COM WWW.ACTIVARCPG.COM
ACPG SOUTHEAST (THOMAS ENTERPRISES): FT MEYERS, FL ACPG WEST COAST (SAMSON): COMMERCE, CA WAREHOUSES: DALLAS TX, LANCASTER PA, ATLANTA GA, CHICAGO, IL, Seattle WA 5-11-12

HINGED DOOR MODELS - RECESSED

